

The following **Figure 5.1** shows the cable signals and the wire colours for the signals on the USB-RS485-WE cable.

